



GROUNDING A CORNERLOC OR FREESTANDING SYSTEM

NOTES:  
 ALL SYSTEMS MUST BE CONNECTED TO BUILDING GROUND AT A SINGLE LOCATION.  
 SPECIFIC METHOD OF CONNECTION VARIES BY UNDERSTRUCTURE.  
 APPROVAL OF PROJECT ELECTRICAL ENGINEER RECOMMENDED.